


PERFUME DISPENSER FUNCTION & USE INSTRUCTION



BUTTON	FUNCTION & INSTRUCTION
POWER	<p>Power ON/OFF Power ON, the dispenser work as default setting automatically, and it spray once. the LCD shows power OFF, all the settings are cleared. the LCD shows nothing.</p> <p>Power OFF Press once, OFF lights up which means the dispenser does not work, and the clock keeps running. The LCD shows Press twice, ON lights up which means the dispenser is working. In SETTING mode, the button is useless.</p>
SPRAY	<p>In SETTING mode, press the button to adjust each option. Press for more than 2 seconds to fast adjust. In WORKING mode, the button is useless.</p>
+/SET	<p>In SETTING mode, after adjusting, press the button to confirm adjusting; press MODE button to cancel. In WORKING mode, the button is useless.</p>
CONFIRM	<p>Press the button, the dispenser enters into SETTING mode: In SETTING mode, if not press MODE, +/SET, or CONFIRM button in 10 seconds, the dispenser will quit SETTING mode automatically.</p>
MODE	<p>Press "MODE" LCD shows:</p> <p>≡ flashes, press +/SET to change to the required spray amount (1, 2, or 3 shots), after select, press CONFIRM. The dispenser will enter into spray interval setting automatically.</p> <p>Press "MODE" INTERVAL 00:30</p> <p>Press "MODE" WEEK ON MO</p> <p>INTERVAL shows, 00:30 flashes, press +/SET to select required spray interval (1, 2, 59 minutes or 1, 2, 3, 4 hours), after select, press CONFIRM. The dispenser will enter into spray day-MONDAY setting automatically.</p> <p>WEEK and MO show, ON flashes. Press +/SET to select ON or OFF, after select, press CONFIRM. The dispenser will enter into spray day-TUESDAY setting automatically.</p>

